










Quick Installation Guide

PEAB-DSL-RTMD-4

TI ADSL2/2+ 4-PORT ROUTER


Package Contents:

- ◆  TI ADSL 2/2+ 4- PORT Router
- ◆  CD-ROM containing Manual
- ◆  Ethernet Cable (CAT5 UTP Straight-Through)
- ◆  ADSL Cable (Standard telephone cable)
- ◆  Power Adapter
- ◆  Quick Installation Guide hardcopy
- ◆  Splitter




Connect Hardware

TI ADSL2/2+ 4-PORT ROUTER



LED Indicators


TI ADSL2/2+ 4-PORT ROUTER




Label	Status	Indicates
PWR	On	Power is on
	Off	Power is off
LAN 1/ LAN 2/ LAN 3/ LAN 4	Flashing	Flashes when data is being sent or received on the LAN connection.
	On	Indicates a link to your LAN or Network card is active.
ADSL	Off	Indicates no link to LAN
	Flashing	An active WLAN session
	On	A valid ADSL connection
	Off	No ADSL connection.

Setting Up Your Computer

1. Select **Obtain an IP Address automatically**: by clicking once in the circle. Click **OK** button to confirm and save your changes, and the close the Control Panel.




2. Release IP
3. Renew IP
4. Check Default Gateway:
192.168.1.1.




Device Configuration


1. Launch your PC web browser and enter the URL: **http://192.168.1.1**.



2. In the Username prompt type **Admin** and in the Password prompt type **Admin** then click **OK** button coming setup page.



3. Please
 - ① Enter the USER ID
 - ② Enter the Password.
 - ③ Select Protocol from the list.
 - ④ Enter the VPI, VCI value.
 - ⑤ Click Save All.
 - ⑥ Click Reboot.You can enjoy the internet immediately.



Note: for more complete information on the device, please see the full manual which is included on the CD.